



# Accessories for chemical products

## → POMPE 5000

01/10

For easier use of CARLYCLEAN detergent, of CARLYBIO decontaminant and of CARLYPRO detergent decontaminant.



### ■ Applications

- 5-L pressure spray for liquids (without solvent).

### ■ Directions for use

- PE and PP bottle.
- Brass piston rod.
- Viton gaskets.
- Maximum pressure = 3 bar.
- Variable jet: vaporised or strong.
- Compatible with solvent-free liquids.
- Incompatible with derivative petroleum products, solvents, ...
- Presence of a safety valve.

### ■ Mode d'emploi

- Pour the liquid into the pump by keeping enough space for air: this air, once compressed, will provide the correct pressure.
- Fit and firmly screw in the bottle pump piston.
- Actuate the pump bar in order to build up a sufficient pressure inside the pump.
- Adjust the jet (spray or strong jet) by means of the forward nozzle end, on the spray lance.



# Accessories for chemical products

## → POMPE 5000

01/10

### ■ Precautions for use

- \* After each use, discharge the pressure from the bottle by pulling out the safety valve relief bar.
- \* After use, rinse the pump and spray lance with clean water.
- \* Do not open the pump when pressurized.
- \* Avoid direct exposure of the pump to sunlight and protect the pump from freezing temperatures.
- \* Do not keep the pump next to hot temperature sources.
- \* Do not spray toxic or poisonous products or substances towards persons or animals.

### ■ Technical features

CARLY references	Volume (Litre)	Maximal working pressure (bar)	Packaging
POMPE 5000	5	3	Pump

### ■ Weights and packaging

CARLY references	Unit weight (kg)	Packaging unit
POMPE 5000	2,02	1